



1. Product Overview



- | | | |
|-------------------------|-----------------|----------------------------------------|
| 1 Control Panel | 2 Power Switch | 3 Handle |
| 4 Front Infrared Sensor | 5 Filter Basket | 6 Side Infrared Sensor |
| 7 Water Sensor | 8 Brush | 9 Water Outlet |
| 10 Charging Port | 11 Suction Port | 12 Scraper |
| 13 Track | 14 Wheel | 15 Wireless Charging Module (Optional) |

2. Control Panel



Control Panel	Meaning	Operation
On/Off	Turn On / Set Up / Save Settings	Hold 3 seconds to turn on & set up. Tap to save settings & start cleaning.
Turbo	Turbo On / Off	LED On = Turbo, LED Off = Standard Cleaning
Cleaning	Setting Cleaning Areas	Bottom LED On = Floor only; Top LED On = Wall only; *Both LEDs On = Wall & Waterline first, then floor; *Both LEDs Off = Full coverage
Run Time	0.5 h / 1 h / 2 h / Low Battery	1/2/3 LEDs or Off = Select Cycle
AI Timer	24 h / 48 h / 72 h / Off	1/2/3 LEDs or Off = Scheduled Cleaning Interval
*Error	E1-E6 Error Codes	See Troubleshooting
*Battery	20-100% (Charging)	LEDs On / Flashing

*Important Cleaning Modes Explained

Wall & Waterline first, then floor

Recommended for most cleaning needs; Does not clean tanning ledges or other shallow areas.


Full coverage

Cleans Floor → Wall → Waterline to cover all areas (Includes tanning ledges); May use more power than Wall & Waterline first, then floor.

3. Turn On & Charge


Turn on

See power switch at the front and turn it **ON**.



Charge


1. Remove charging port cover.




2. Plug in the supplied charger to 100–240 VAC.

(The plug for the Australian market is Type I - 3 pins)

3. Three LEDs solid = fully charged.



4. Disconnect and close the cover.



4. Connect To Wi-Fi


1. Enable Bluetooth & WiFi on your phone.

2. Hold Cleaning Mode for 3s. After hearing a tone, it is ready to pair.

3. Search and connect device in the "iGarden Robotics" App, when the starts flashing.


4. Once the Control Panel shows up, the WiFi is set.

Scanning QR Code below to download:



5. Quick Start


1. Go: Hold ON/OFF for 3 s. LEDs flash—set options—tap again to start.



Note: Control panel on—no ON/OFF hold.
Only hold ON/OFF if control panel is off.

2. Gently rotate in different directions before place it into water.

3. Submerge the cleaner within 3 minutes when power-on.



Warnings

- Do not swim during operation.
- Charge only with the supplied adapter & battery.
- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Support

✉ support@igarden.ai

🌐 www.igarden.ai

☎ Toll-free(US): (+1)888-880-3320

☎ Toll-free(AU): (+61)1800-716-885

See the full guide inside the box for detailed instructions.

